

INSTRUCTIONS

Thank you for purchasing our innovative Bye Bye Standby energy saving starter kit. This money and energy saving starter kit is a simple way to take control of your home, your finances and your energy consumption, whilst at the same time reducing your carbon footprint (CO₂). Whilst practical, it's easy to install, easy to use and is really convenient. With Bye Bye Standby you can power down every appliance in your home at the touch of a button, giving you peace of mind, saving you money, reducing the risk of fire and helping to protect the environment.

Independent research has shown that Bye Bye Standby can save the average family household around £38-40 a year, whilst reducing CO₂ emissions by up to 166kgs per year! Bye Bye Standby gives you convenient and simple control of your household devices, even your table lamps. Just one touch of the relevant button on your remote control will cut the power to specific sections of your house or your entire home...you choose!

For use in the home with the following devices and many more:

- Televisions
- DVD players
- Set top boxes
- MP3 players
- Video players
- Stereos
- Printers
- Lights
- Games Consoles
- Computers
- Phone Chargers

How to use Bye Bye Standby

Individual Socket Control:



Depending on your preference, you can control one or all of your Bye Bye Standby sockets at the same time. Firstly, make sure your Bye Bye Standby remote and your Bye Bye Standby socket are set to the same 'zone' code (red dial). The 'zone' code refers to the letter (A to H).

For example... set your Bye Bye Standby remote to 'A' and one of your Bye Bye Standby sockets to 'A1'.

Plug your appliance into the Bye Bye Standby socket. Now plug the Bye Bye Standby socket into a mains wall socket.

Note: if you have a 4-way adapter or extension lead you can control 4 appliances instead of just one from the same socket.

You can now switch that appliance on and off wirelessly from up to 30m away by pressing the left button marked '1' (left buttons on the remote switch ON, right buttons switch OFF). For total flexibility you can set individual appliances to different codes (1 to 8) or if you prefer, you can set all appliances in the same room to the same code (e.g. A1) thus controlling more than one appliance at a time. There really is no right or wrong way, so go ahead, have a play!



Page function: when set to Page I your Bye Bye Standby remote will control appliances which are set to numbers 1-4. If you switch the remote to Page II then you will be able to control appliances set to 5-8.

One Button Control:

For multiple socket control, ensure you turn on the 'Group' function on the side of each Bye Bye Standby socket, and ensure all sockets are set to the same 'zone' code as the Bye Bye Standby remote (eg. 'A'). You can now control all Bye Bye Standby sockets, irrelevant of the appliance code (i.e. 1-8) with just one button. Once set up, simply push the button marked 'Group' on your Bye Bye Standby remote and watch all connected appliances power down! It's that easy! For added convenience you can exclude certain Bye Bye Standby sockets from the 'group function by simply leaving the group function on the side of the socket in its 'off' position.

Troubleshooting: If the units do not work...

- Check the battery in the Remote Control by pressing any button, if the LED lights up, the battery is ok.
- Ensure you are using the units within operable limits.
- Check the House and Unit Codes are compatible on Remote Control and receiver.
- Check LED Power On indicator on the receiver.
- Check the receiver is not overloaded (check the product rating label).
- Receivers must be installed at least 1 metre apart.

Important:

For indoor use only. Keep away from all sources of water or moisture. Not for use with any electrical appliance using a heating element such as an electric fire. In this instance a heavy duty Bye Bye Standby socket should be used, available separately. Do not overload. Adult installation only. Use only as directed.

Register your product, activate your warranty and add to your starter kit by visiting: www.byebyestandby.co.uk

Other Bye Bye Standby products include: additional Bye Bye Standby sockets (singles), wireless on/off wall switches, key-ring remote controls, motion sensors and much more.

For customer services or technical support call: 01908 357707 or email: enquiries@homeprideuk.com

SPECIFICATIONS:

Frequency: 433.92MHz etc
 Up to 64 digital codes
 3V CR2032 Lithium Battery (included)
 Operating voltage: 230V/50Hz
 Max current per receiver 4 amps / (1000watt)
 CE 0560 APPROVED

